

# Rugged Tablet PC EM-I81F

## Win10 OS Product Manual

---

### Attention :

- The manual in this guide refer to the windows10 system. If you are using other OS, some operations some operations may not suit you.
- The manual describe the general functions of most models. Your computer may not have some functionality, or some features on your computer are not described in the manual.
- This manual applies the following models: EM-I81F Rugged Tablet PC.
- The illustrations in this manual may be different from the product itself. Please prevail in kind.

# Content

I . File version information .....	4
II . Device performance structure .....	5
III . Device initialized setting .....	8
IV . Desktop layout .....	14
1. Windows10 start .....	14
2. Charm menu bar .....	15
3. APP Interface introduction .....	17
V . System setting .....	19
1. Display application icon .....	19
2. System information .....	21
3. Quick start .....	22
4. System setting .....	23
5. Quick start and setup .....	24

## I . File version information

File Name	EM-I81F Win10 OS Product Manual				
File No.	0001	Version		V1.0	
Publishing Date	2017-04-19	Pages			
Update Records					
No.	Update Name	Version	Date	Content	Department
1	YDXX-01	V1.0	2017-04-19	First published	Service FAE department

## II. Device performance structure


### Front of the device

(touch screen/display/front camera/indicator/light sensor)


Front camera/Indicator/light sensor



## The back of the device (speaker/rear camera/NFC sensing area)




## Directly above the device




## Directly below the device



## Left side of device



## Right side of the device




### III. Device initialized setting


#### 1. User setup wizard

##### 1 ) Language setting

A. Click "Yes" to go to the next step depending on the language you want.




B. Select the area of use according to language.




## 2 ) Keyboard layout and language setting

A. choose the keyboard layout and language you like, click "yes" to enter the next step.




B. If one keyboard cannot be satisfied, add a second keyboard or skip here.



### 3 ) Network setting

Choose the network you want to connect and enter your password. (It is recommended to skip the network connection , otherwise it may take too long for the system to check for updates.)




### 4 ) User license agreement

This is the Microsoft software license agreement, click "accept" to enter the next step.




## 5 ) Username and password settings

A. Setting the username and go to the next step.




B. Enter the password, click "next" the device will restart, do not do anything else during the device restart. (Do not need to set password and click the "next" ).



## 6 ) Personalized setting

### A. Making Cortana as your personal assistant.




### B. Choose privacy settings for your device.



## 7 ) Complete setting

Wait for the system to enter the desktop and do not shut down the computer.



# IV. Desktop layout

## 1.Windows10 start



- ① **start icon** — Quick launch of installed applications.
- ② **search for** — Enter the key character search page or open the application.
- ③ **task view** — Open multiple tasks to quickly switch applications with this icon.
- ④ **IE browser**
- ⑤ **file explore** — For quick viewing of recently used files and administration files.
- ⑥ **store** — Download installation application.
- ⑦ **email** — Log in to email account to receive and send mail.


## 2.Charm menu bar

Pressing the Start button to open the charm menu bar, which including: Start, Device, Settings, and Search program.




- ① **battery level** — View the system of battery voltage.
- ② **network** — View the status of device management network connections.
- ③ **sound** — Control audio and adjust volume.
- ④ **pen** — Pen and Windows ink settings.
- ⑤ **keyboard** — Touch keyboard button.
- ⑥ **language** — Set up and manage the current input method.
- ⑦ **time/date** — Time and date setting.
- ⑧ **action center** — View system notification information.


### Including: browse files, settings, power keys, App.




Sleep, shut down, restart



Search for files and applications




Device system



More APP

### 3.APP Interface introduction

Click "Operation Center"——"Tablet Mode" as shown in the picture below, you can see many programs fixed on the screen, these applications are displayed in the form of "tiles", and can be accessed with one click. You need to log in to your Microsoft account before the application is working.



Tablet mode



①start

②pinned tiles

③all apps

④user

⑤setting

⑥power


**Add "magnet" file :** All app — select the application icon, mouse with right key — pin to start — return to the fixed magnet to view the application.

**Delete magnet file :** fixed magnet, mouse with right key — select cancel screen.


# V. System setting

## 1. Display application icon


A. Click on the right mouse key and select “personalize” , as below picture.




B. Personalize window, click “theme” with the mouse left key.




C. Click “Desktop icon setting” with the mouse left key.



D. Tick in front of the computer icon and click OK.



## 2.System information



Click the right mouse key or touch the computer icon to open the extension option. Click on "properties" to view system information, Windows system version, hardware configuration information, computer name, Windows activation, etc.

## 3.Quick start



Click the right mouse button or click the touch to start the icon, open the advanced boot interface, and open the corresponding function.

**1.Apps and features** — Manage installed applications and drivers, update drivers and applications.

**2.Mobility center** — Adjust the screen brightness, volume size, detect battery power, and set the direction of the screen.

**3.Power options** — Management about the power settings, on the battery power turn off screen after how long times, PC go to sleep after how long times.

**4.Event viewer** — View Windows logs, custom views, subscriptions, application and service logs.

**5.System** — View system and hardware configuration information.

**6.Device Manager** — Manages device drivers, disable and enable devices, unknown device driver installation management.

**7.Network connection** — Quickly start the network setup. On this page, you can set up the mobile phone network, Wi-Fi and Ethernet.

**8.Disk management** — Local and external disk management, partitioned disk format.

**9.Computer management** — Opening computer system tools, storage, services, etc.

**10.Windows PowerShell** — CMD command runs the window.

**11.Windows PowerShell ( Admin )** — CMD administrator: commands to run windows.

**12.Task manager** — Force the system to turn off the background programs and services, and check the running state of the computer.

**13.Setting** — Open the system settings.

**14.File explores** — Open and check file.


**15.Search** — Search for a web site or application.

**16.Run** — CMD running window.

**17.Shut down or sign out** — Turn off the computer, sleep in, restart and sign off the user.

**18.Desktop** — Back to desktop.

## 4.System setting



**1.System** — Display settings, notifications & action, power & sleep, battery, storage, tablet mode, multitasking, projecting to this PC, shared experiences, about, remote desktop (Windows10 HOME version is not supported).

**2.Device** — Bluetooth & other devices, printer & scanner, mouse, typing, pen & Windows ink, auto play, USB.

**3.Network and Internet** — View network status, Wi-Fi settings, cellular settings, ethernet, dial-up, VPN settings, airplane mode, mobile hotspot, data usage, proxy settings.

**4.Personalization** — Background setting, colors, lock screen, theme setting. (Start menu bar settings, taskbar) these two items need to be set up after system activate.

**5.Apps** — Apps and features (can be applied to install, modify or uninstall), default apps (can add default startup applications), offline maps, Apps for websites.

**6.Account** — View your info, add e-mail and apps accounts, sign-in options, access work or School, family & other people, sync your settings.

**7.Time and language** — The time and date can be set at the interface (when the device is connected to the Internet when it opens automatically, it can synchronize with the network), Region & language (Region setting, adding other language packages), speech settings.

**8.Game** — Control how game bar opens and recognizes you game. Record game clips, screenshots, and broadcast using game bar.


**9.Easy of access** — Can be settings, narrator, magnifier, high contrast, closed captions, keyboard, mouse, other options.

**10.Privacy** — privacy can be settings, including general, location, camera, microphone, Notifications, speech, inking & typing, account info, contacts, calendar, call history, app diagnostics.

**11.Update & security** — Windows update, windows defender, backup systems, troubleshooting, recovery systems, activation, find my devices, for developer, Windows insider program.

## 5.Quick start and setup

1 ) Open show touch keyboard button — more touch on the taskbar or mouse with right key to choose it.



2 ) System Activation — the device cannot be activated during networking, please refer to the right picture, and then try to activate again after synchronizing the time zone.

